


FITZO — Overdrive Avant-garde/Amp Enhancer

Owner's Manual

Thank you for choosing **FITZO**. Please read this document to get the best use, blues & joy of this all the way unique Overdrive Avant-garde/Amp Enhancer effect.

External controls:



FITZO tips & tricks:

It could take some time to get a grip about all possibilities in this pedal. We encourage you to try several different combinations of the outboard control settings as each will impart its own unique character on your tone. Also, try to adjust the volume control of your guitar and you will see how flexible, responsive and real **FITZO** is. Our wish is that you'll like what you hear and feel. Also try **FITZO** before or after your other pedals to see how good they might work together!

Every pedal is 100% handmade, tested and carefully adjusted by the original designer in Sweden. If you happen to remove the bottom plate and find some internal controls, remember these parts are **not** meant to be adjusted by the user—because of warranty reasons. More information about **FITZO**, and collaborating products, is available at www.himmelstrutz.com.

- Even though the power consumption is low (2-3 milliampere) the battery needs to be replaced when the LED gets weak or if the tone changes. To change the battery, unscrew the four screws on the bottom plate, bring out the old 9 volt battery (6LR61) and replace it with a new. Then attach the bottom plate with the four screws. *Never use FITZO without the bottom plate!*
- If you play loud, always use ear protection. It's easy to forget, but not a good idea in the long run!
- Unplug the input cord when not using the pedal—if powered by a battery—to save the battery (and environment).
- Don't forget to have fun, with ear protection and a huge glass of gin if that's what you can handle.

Good luck!

Joakim Hedeby, Himmelstrutz Elektro Art, Sweden